

SiriMoto Phase 2 Strut Bar Installation Steps

1. Remove the four M10 strut mount nuts.
 - a. Note: Hatchback models have a black bracket in place, be sure to remove this piece as well, if applicable.
2. Install the SiriMoto strut bar, and loosely fasten the provided nuts.
3. Tighten the M10 nuts to 45lb/ft.
4. Tighten the strut bar bolt/nut combo to about 27lb/ft.
5. Finish by moving any hose, and/or battery cables, away from the strut bar to prevent rubbing and wear in the long term.
 - a. Note: The EVAP hose can often be simply rotated downwards, at the hard-line coming off the firewall, to move it away from the aluminum strut bar.

For an install video, check out the PRO Car Studio YouTube Channel:

NOTE: Do not apply any anti-seize or lubricant on the bolt threads. This can lead to over-tightening, thus damaging the parts and/or hardware.

