

SiriMoto Phase 2 Carbon Fiber Strut Bar Installation Steps

1. Remove M10 strut mount nuts (and black bracket if applicable).
2. Install the SiriMoto mounting brackets, and loosely fasten the provided nuts.
3. Install one end of the CF Strut Bar to one of the brackets, by loosely fastening the provided bolts.
4. Turn the CF bar while holding the loose end stationary, in order to extend its length and allow it to reach the opposing bracket, then loosely fasten the M10 bolts.
5. Tighten all of the M10 hardware to about 45lb/ft, starting with the mounting bracket nuts, then the strut bar bolts.
6. With the CF bar at zero-tension, turn the bar about 1/16th of a turn to provide outward tension, then tighten the jam nuts.
7. Finish by applying the SiriMoto decal, and use the zip ties to hold the evap hose, and/or negative battery cable, away from the strut bar to prevent rubbing and wear in the long term.

NOTE: Do not apply any anti-seize or lubricant on the bolt threads. This can lead to over-tightening, thus damaging the parts and/or hardware.